

ASSEMBLY & INSTALLATION NOTES

JUBU Carbon engine lid (louvre) (JU00117PRD)

for Emira

Please follow the instructions in this manual for a proper assembly & installation of the JUBU Carbon engine lid (louvre) for Emira.

Please find in this document:

1. PART LIST
2. ASSEMBLY & INSTALLATION NOTES

1. PART LIST for product JU00117PRD

#	ITEM	ART-NO.	UNITS
1	Carbon fiber engine lid (dry carbon)	JU00881ART	1
2	Shim 2.5mm	-	1
3	Shim 3mm	-	1
4	Bodywork adhesive	VM00081	1
5	Bodywork adhesive primer	JU00183ART	1
6	Wool dauber	VM00094	1



Fig 1: JUBU carbon fiber engine lid

2. ASSEMBLY & INSTALLATION NOTES

Level of difficulty: **MEDIUM**

Required time: **1h - 2h** (depends on experience, available tools & skills)

1. Remove the OEM rear window (glass panel) and the remaining glue.



NOTE: Use a professional cutting tool and wire!

2. Test fit the carbon engine lid (1) and check if one of the shims (2, 3) are necessary in the top center below the engine lid. (like at the rear window install)
3. Use the wool dauber (6) to apply primer (5) to the areas of the tail gate and the carbon engine lid (1) where adhesive will be added.
4. Put bodywork adhesive (4) on the tail gate as done with the OEM glass panel. If necessary, put one of the shims (2, 3) in position.
5. Position the Carbon engine lid (1) carefully and tape it to the tailgate until the bodywork adhesive is fully cured.



NOTE: Make sure to use tape that does not attack the clear paint and is easily removable!



NOTE: The bodywork adhesive (4) has to cure for at least 90 minutes!

If you have any questions or need additional information, please contact us by email:

info@jubu-performance.com

JUBU Performance GmbH

Saxenegg 3a, 4323 Münzbach, AUSTRIA