

ASSEMBLY & INSTALLATION NOTES

JUBU upgrade belt drive pulley kit (JU00004PRD)

for 2GR-FE 7PK & 8PK

Please follow the instructions in this manual for a proper assembly & installation of the JUBU upgrade belt drive pulley kit 7PK & 8PK for 2GR-FE.

Please find in this document:

- 1. PART LIST
- 2. ASSEMBLY & INSTALLATION NOTES

1. PART LIST for product JU00004PRD

#	ITEM	ART-NO.	UNITS
1	Upgrade pulley bearing	JU00055ART	2
2	Upgrade pulley sleeve 7PK & 8PK	JPP620118	2
3	Upgrade pulley spacer 7PK & 8PK	JPP620144	1

Note: The Upgrade bearings (1) and the Upgrade pulley sleeves (2) are pre-assembled according to Fig 2 and Fig 3.



Fig 1: Scope of delivery

FILE: INSTA_MANUAL_JUBU_upgrade_belt_drive_pulley_kit_2GR-FE_Set

REL_DATE: 19.07.2023 Martin

VERSION: 1.3 final



(I) Engine mounted pulley




Fig 2: Engine mounted pulley

(II) Tensioner pulley




Fig 3: Tensioner pulley

FILE: INSTA_MANUAL_JUBU_upgrade_belt_drive_pulley_kit_2GR-FE_Set **REL_DATE:** 19.07.2023 Martin

VERSION: 1.3 final



2. ASSEMBLY & INSTALLATION NOTES

- 1. Disassemble the OEM engine mounted pulley and belt tensioner pulley.
- 2. Screw the pre-assembled engine-mounted pulley (/) onto the engine as shown in Fig. 4 using the OEM screws, tightening them with OEM torque (43Nm) and using LOCTITE 243 locking lacquer.
- 3. Screw the pre-assembled belt tensioner pulley (II) onto the belt tensioner as shown in Fig. 4 using the OEM screws, tightening them with OEM torque (43Nm) and using LOCTITE 243locking lacquer.
- 4. NOTE: These Pulleys can be used for 7PK and 8PK belt systems, the belt might not run in the center of the pulley.




Fig 3: Correct assembly of the upgrade belt drive pulleys.

If you have any questions or need additional information, please contact us by email: info@jubu-performance.com

JUBU Performance GmbH

Saxenegg 3a, 4323 Münzbach, AUSTRIA

FILE: INSTA_MANUAL_JUBU_upgrade_belt_drive_pulley_kit_2GR-FE_Set REL_DATE: 19.07.2023 Martin

VERSION: 1.3 final